

# Supplies

## Compatibility Table



### LEXMARK MONO LASER SUPPLIES

Printer Models	Return Programme Cartridges				Regular Cartridges			Other Supplies	
	Extra High Yield Print Cartridge	High Yield Print/ Toner Cartridge	Print/ Toner Cartridge	Label Print Cartridge	Extra High Yield Print Cartridge	High Yield Print/ Toner Cartridge	Print/ Toner Cartridge	Staples	Photo-conductor Unit
Lexmark E120 (1)			0012016SE				0012036SE		0012026XW
Lexmark E210							0010S0150		
Lexmark E220			0012S0400				0012S0300		
Lexmark E232 (1)			0024016SE				0024036SE		0012A8302
Lexmark E240 (1)			0024016SE				0024036SE		0012A8302
Lexmark E320, E322		0008A0478	0008A0476			0008A0477	0008A0475		
Lexmark E321, E323		0012A7405	0012A7400			0012A7305	0012A7300		
Lexmark E330, E332n, E340, E342 (1)		0034016HE	0024016SE			0034036HE	0024036SE		0012A8302
Lexmark E250 (1)			0E250A11E				0E250A21E		0E250X22G
Lexmark E350, E352 (1)		0E352H11E	0E250A11E			0E352H21E	0E250A21E		0E250X22G
Lexmark E450		0E450H11E	0E450A11E			0E450H21E	0E250A21E		0E250X22G
Lexmark T420		0012A7415	0012A7410			0012A7315	0012A7310		
Lexmark T430		0012A8425	0012A8420			0012A8325	0012A8320		
Lexmark T520, X520, T522, X522		0012A6835	0012A6830	0012A6839		0012A6735	0012A6730		
Lexmark T620, T622		0012A6865	0012A6860	0012A6869		0012A6765	0012A6760	0011K3188	
Lexmark T630, X630, T632, X632, T634	0012A7465 (2)	0012A7462	0012A7460	0012A7468	0012A7365 (2)	0012A7362	0012A7360	0011K3188	
Lexmark T640, T642, T644 (1)	0064416XE (3)	0064016HE	0064016SE	0064404XE <sup>®</sup> 0064004HE	0064436XE (3)	0064036HE	0064036SE	0011K3188	
Lexmark W812							0014K0050		
Lexmark W820, X82							0012B0090	0012L0252	
Lexmark W840							00W84020H	0025A0013	00W84030H
Lexmark X830, X832							00X8302KH	0012L0252	
Lexmark X215							0018S0090		
Lexmark X340, X342		0X340H11G(5)	0X340A11G			0X340H21G(5)	0X340A21G		0X340H22G
Lexmark X422		0012A4715	0012A4710			0012A3715	0012A3710		
Lexmark X642, X644, X646	0X644X11E (4)	0X644H11E	0X644A11E		0X644X21E (4)	0X644H21E	0X644A21E		
Lexmark X850, X852, X854							0X850H21G	0025A0013	0X850H22G
Optra™ E310/E312/E312L						0013T0101	0013T0301		
Optra E							0069G8256		0069G8257
Optra K 1220							0012A4605 0011A4097 (2 packs)		0011A4096 (with cartridge)
Optra M410/M412					0017G0154	0017G0152	004K00199 <sup>®</sup>		
Optra N							00140109A		
Optra S		001382925	001382920	001382929		001382625	001382620		
Optra Se 3455			0012A0825	0012A0829			0012A0725		
Optra T/ T610/T612/T614/T616		0012A5845	0012A5840	0012A5849		0012A5745	0012A5740		
Optra W810							0012L0250	0012L0252	0012L0251
Lexmark 4019-28-29, WinWriter™ 600							001380520		
Lexmark 4037-5E, 4047-5E, 4047-5W,							001382760		
ValueWriter™ 300/600, WinWriter 400							001382760		
Lexmark 4039/4039+						001380950	001380850		
Lexmark 4039 10+, 4049, Optra L/R series						001382150	001382100		

(1) Supplies designed for use only in Europe, Middle East and Africa.

(2) Compatible with Lexmark T632, T634, X632.

(3) Compatible with Lexmark T644 only.

(4) Not compatible with Lexmark X642.

(5) Not compatible with Lexmark X340.

(6) Not compatible with Optra M412

\*New

# LEXMARK COLOUR LASER SUPPLIES

## Return Programme Cartridges

Model	Black Extra High Yield Print Cartridge	Cyan Extra High Yield Print Cartridge	Magenta Extra High Yield Print Cartridge	Yellow Extra High Yield Print Cartridge	Black High Yield Print Cartridge	Cyan High Yield Print Cartridge	Magenta High Yield Print Cartridge	Yellow High Yield Print Cartridge	Black Print Cartridge	Cyan Print Cartridge	Magenta Print Cartridge	Yellow Print Cartridge
Lexmark C522									00C5220KS	00C5220CS	00C5220MS	00C5220YS
Lexmark C524					00C5240KH	00C5240CH	00C5240MH	00C5240YH	00C5220KS	00C5220CS	00C5220MS	00C5220YS
Lexmark C530					00C5220KS	00C5220CS	00C5220MS	00C5220YS	00C5200KS	00C5200CS	00C5200MS	00C5200YS
Lexmark C532						00C5240CH	00C5240MH	00C5240YH	00C5220KS	00C5220CS	00C5220MS	00C5220YS
Lexmark C534		00C5340CX	00C5340MX	00C5340YX	00C5240KH	00C5240CH	00C5240MH	00C5240YH	00C5220KS	00C5220CS	00C5220MS	00C5220YS
Lexmark C750, X750					0010B042K	0010B042C	0010B042M	0010B042Y	0010B041K	0010B041C	0010B041M	0010B041Y
Lexmark C752, X752, X762					0015G042K	0015G042C	0015G042M	0015G042Y	0015G041K	0015G041C	0015G041M	0015G041Y
Lexmark C752L, C760									0015G041K	0015G041C	0015G041M	0015G041Y
Lexmark C770					00C7700KH	00C7700CH	00C7700MH	00C7700YH	00C7700KS	00C7700CS	00C7700MS	00C7700YS
Lexmark C772, X772	00C7720KX	00C7720CX	00C7720MX	00C7720YX	00C7700KH	00C7700CH	00C7700MH	00C7700YH	00C7700KS	00C7700CS	00C7700MS	00C7700YS
Lexmark C780	NEW				0C780H1KG	0C780H1CG	0C780H1MG	0C780H1YG	0C780A1KG	0C780A1CG	0C780A1MG	0C780A1YG
Lexmark C782, X782	NEW	0C782X1KG	0C782X1CG	0C782X1MG	0C782X1YG	0C780H1KG	0C780H1CG	0C780H1MG	0C780H1YG	0C780A1KG	0C780A1CG	0C780A1MG

## Regular Cartridges

Model	Black Extra High Yield Print Cartridge	Cyan Extra High Yield Print Cartridge	Magenta Extra High Yield Print Cartridge	Yellow Extra High Yield Print Cartridge	Black High Yield Print / Toner Cartridge	Cyan High Yield Print / Toner Cartridge	Magenta High Yield Print / Toner Cartridge	Yellow High Yield Print / Toner Cartridge	Black Print / Toner Cartridge	Cyan Print / Toner Cartridge	Magenta Print / Toner Cartridge	Yellow Print / Toner Cartridge
Lexmark C500, X500, X502	NEW				0C500H2KG	0C500H2CG	0C500H2MG	0C500H2YG	0C500S2KG	0C500S2CG	0C500S2MG	0C500S2YG
Lexmark C510					0020K1403	0020K1400	0020K1401	0020K1402	0020K0503	0020K0500	0020K0501	0020K0502
Lexmark C522									00C5222KS	00C5222CS	00C5222MS	00C5222YS
Lexmark C524					00C5242KH	00C5242CH	00C5242MH	00C5242YH	00C5222KS	00C5222CS	00C5222MS	00C5222YS
Lexmark C530					00C5222KS	00C5222CS	00C5222MS	00C5222YS	00C5202KS	00C5202CS	00C5202MS	00C5202YS
Lexmark C532						00C5242CH	00C5242MH	00C5242YH	00C5222KS	00C5222CS	00C5222MS	00C5222YS
Lexmark C534		00C5342CX	00C5342MX	00C5342YX	00C5242KH	00C5242CH	00C5242MH	00C5242YH	00C5222KS	00C5222CS	00C5222MS	00C5222YS
Lexmark X560	NEW				0X560H2KG	0X560H2CG	0X560H2MG	0X560H2YG		0X560A2CG	0X560A2MG	0X560A2YG
Lexmark C720, X720					0015W0903	0015W0900	0015W0901	0015W0902				
Lexmark C750, X750					0010B032K	0010B032C	0010B032M	0010B032Y	0010B031K	0010B031C	0010B031M	0010B031Y
Lexmark C752, C762, X752, X762					0015G032K	0015G032C	0015G032M	0015G032Y	0015G031K	0015G031C	0015G031M	0015G031Y
Lexmark C752L, C760									0015G031K	0015G031C	0015G031M	0015G031Y
Lexmark C770					00C7702KH	00C7702CH	00C7702MH	00C7702YH	00C7702KS	00C7702CS	00C7702MS	00C7702YS
Lexmark C772, X772	00C7722KX	00C7722CX	00C7722MX	00C7722YX	00C7702KH	00C7702CH	00C7702MH	00C7702YH	00C7702KS	00C7702CS	00C7702MS	00C7702YS
Lexmark C780	NEW				0C780H2KG	0C780H2CG	0C780H2MG	0C780H2YG	0C780A2KG	0C780A2CG	0C780A2MG	0C780A2YG
Lexmark C782, X782	NEW	0C782X2KG	0C782X2CG	0C782X2MG	0C782X2YG	0C780H2KG	0C780H2CG	0C780H2MG	0C780A2KG	0C780A2CG	0C780A2MG	0C780A2YG
Lexmark C910, C912, X912					0012N0771*	0012N0768	0012N0769	0012N0770				
Lexmark C920					00C9202KH	00C9202CH	00C9202MH	00C9202YH				
Lexmark C935	NEW								0C930H2KG	0C930H2CG	0C930H2MG	0C930H2YG
Lexmark X940, X945	NEW								0X945X2KG	0X945X2CG	0X945X2MG	0X945X2YG
Optra C710					0010E0043*	0010E0040	0010E0041	0010E0042				
Optra Color 1200					0012A1454	0012A1452	0012A1451	0012A1453				
Optra SC 1275					001361751	001361752	001361753	001361754				

## Other Supplies

Model	Black Photoconductor Unit	Photo-conductor Packs	Coating Roll	Fuser Oil/ Oil Bottle	Transfer Kit	Waste Toner Bottle	Corona Charger	Fuser Cleaning Roller	Fuser Kit HV	Fuser Unit	Staple Cartridges
Lexmark C500, X500, X502	NEW	0C500X26G				0C500X27G				0C500X29G	
Lexmark C510		0020K0504				0020K0505				0C500X29G	
Lexmark C522, C524		00C53030X	00C53034X (KCMY)			00C52025X					
Lexmark C532, C534		00C53030X	00C53034X (KCMY)			00C52025X					
Lexmark C720, X720		0015W0904		0015W0906		0015W0907	0015W0918	0015W0905	0015W0909		
Lexmark C750						0010B3100					0012L0252
Lexmark C752, C752L, C760, C762, X752						0010B3100					0011K3188
Lexmark C770, C772, X772						0010B3100					0011K3188
Lexmark C780, C782, X782	NEW					0010B3100					0011K3188
Lexmark C910		0012N0773 (CMY)	0012N0772 (CMY)	00C92035X							0011K3188
Lexmark C912, X912		0012N0773	0012N0772 (CMY)	00C92035X							0011K3188
Lexmark C920		0012N0773	0012N0772 (CMY)	00C92035X							0011K3188
Lexmark C935, Lexmark X940, X945	NEW	0C930X72G	0C930X73G (CMY)			0C930X76G					0025A0013 0021Z0357 (Booklet)
Optra C710				0010E0044	0010E0045						
Optra Color 1200		0012A1450	0012A1455 (CMY)								
Optra SC 1275		001361750									

\* Including coating roll.

# LEXMARK INKJET CARTRIDGES COMPATIBILITY TABLE



COLOUR CARTRIDGES																
up to 120 pages(1)	up to 150 pages(1)	up to 150 pages(1)	up to 260 pages(3)	up to 685 pages(1)	up to 185 pages(1)	up to 185 pages(1)	up to 625 pages(3)	up to 275 pages(3)	up to 220 pages(1)	up to 150 pages(1)	up to 150 pages(1)	up to 280 pages(1)	upto 595 pages(1)	up to 150 pages(1)	up to 150 pages(1)	up to 500 pages(1)
1	15	15A	19	20	24	24A	25	26	27	29	29A	33	35	37	37A	37XL
018CX781E	018C2110E	018C2100E	015M2619E	015MX120E	018C1524E	018C1624E	015M0125E	010N0026E	010NX227E	018C1429E	018C1529E	018CX033E	018C0035E	018C2140E	018C2160E	018C2180E

BLACK CARTRIDGES													
up to 175 pages(1)	up to 175 pages(1)		up to 215 pages(1)	up to 215 pages(1)	up to 410 pages(2)	up to 210 pages(1)	up to 175 pages(1)	up to 175 pages(1)	up to 350 pages(1)	up to 580 pages(1)	up to 175 pages(1)	up to 175 pages(1)	up to 500 pages(1)
14	14A		23	23A	16	17	28	28A	32	34	36	36A	36XL
018C2090E	018C2080E		018C1523E	018C1623E	010N0016E	010NX217E	018C1428E	018C1528E	018CX032E	018C0034E	018C2130E	018C2150E	018C2170E

## Single function printers

Z11, Z31																
Z12																
Z13, i3, Z23, Z25, Z33, Z34, Z35, Z511, Z513, Z515, Z517, Z601, Z602, Z603, Z605, Z611, Z612, Z613, Z614, Z615, Z617, Z640, Z645, Z647																
Z845, Z1300, Z1310, Z1320																
Z1400, Z1410, Z1420																
Z1520																
Z22, Z32																
Z2320 <i>NEW</i>																
Z2420 <i>NEW</i>																
Z42, Z43, Z45, Z51, Z52, Z53, Z54, Z82																
Z55, Z65																
Z703																
Z705, Z715																
Z730, Z735																
Z810, Z812, Z815, Z816, Z818																

## Photo printers

P315, P450																
P350																
P706, P707, P3120, P3150																
P910, P915, P4310, P4330, P4350, P6210, P6250, P6350																

## Multifunction printers

X2310, X2330, X2350, X2450, X2470, X3450, X3470																
X2500, X2510, X2530, X2550, X5070, X5320, X5370, X5490																
X2650 <i>NEW</i>																
X3530, X3550, X4530, X4550																
X3650 <i>NEW</i>																
X4250, X4270, F4270																
X4650 <i>NEW</i>																
X4850, X6550, X6570, X7550																
X5130, X5150, X5190, X6150, X6170, X6190																
X3310, X3330, X3350, X5210, X5250, X5260, X5270, X5410, X5450, X5470, X7170, X7310, X7350, X8310, X8350																
X5495																
X63, X70, X73, X80, X83, X84, X85, X125																
X74, X75, X1110, X1130, X1140, X1150, X1155, X1160, X1170, X1180, X1185, X1190, X1195, X1250, X1270, X1290, X2230, X2240, X2250																
X9350																
Professionnal Series Lexmark X4875 <i>NEW</i>																
Professionnal Series Lexmark X5075 <i>NEW</i>																
Professionnal Series Lexmark X6575 <i>NEW</i>																
Professionnal Series Lexmark X9575 <i>NEW</i>																

(1) up to this number of pages according to ISO Standard 24711. Actual yield may vary based upon documents printed and printer installed. For detail path, please refer to [www.lexmark.com](http://www.lexmark.com).

(2) Upto this number of pages at 5% coverage.

(3) upto this number of pages at 15% coverage.

All inkjet cartridges are designed for use only in Europe, Middle East and Africa.

## MULTI-PACKS



Configuration




Combo Packs						
16+26	17+27	23+24	28+29	32+33	43+44	70+20
0080D2126	0080D2952	018C1419E	018C1520E	0080D2951	0080D2966	0080D2953
•/•/•/•/•	•/•/•/•/•	•/•/•/•/•	•/•/•/•/•	•/•/•/•/•	•/•/•/•/•	•/•/•/•/•

Twin Packs			
1+1	17+17	32+32	70+70
0080D2955	0080D2954	0080D2956	0080D2957
•/•/•/•/•	•/•/•/•/•	•/•/•/•/•	•/•/•/•/•

up to 500 pages(1)	up to 210 pages(1)	up to 210 pages(1)	up to 500 pages(1)		up to 225 pages(3)		up to 275 pages(3)	up to 285 pages(1)	up to 470 pages(3)	up to 650 pages(3)
<b>37XLA</b>	<b>41</b>	<b>41A</b>	<b>43XL</b>		<b>60</b>		<b>80</b>	<b>83</b>	<b>85</b>	<b>88</b>
018C2200E	018Y0141E	018Y0341E	018YX143E		017G0060E		012A1980E	018LX042E	012A1985E	018L0000E

PHOTO CART.					
up to 125 (10x15 cm)	up to 50 (10x15 cm)	upto 110 (10x15 cm)	up to 125 (10x15 cm)	up to 125 (10x15 cm)	up to 110 (10x15 cm)
<b>31</b>	<b>33</b>	<b>35</b>	<b>43XL</b>	<b>40</b>	<b>90</b>
018C0031E	018CX033E	018C0035E	018YX143E	018Y0340E	012A1990E

up to 500 pages(1)	up to 220 pages(1)	up to 220 pages(1)	up to 540 pages(1)	up to 225 pages(2)	up to 410 pages(2)		up to 600 pages(1)	up to 270 pages(1)	up to 1.100 pages(2)	up to 600 pages(2)
<b>36XLA</b>	<b>42</b>	<b>42A</b>	<b>44XL</b>	<b>48</b>	<b>50</b>		<b>70</b>	<b>71</b>	<b>75</b>	<b>82</b>
018C2190E	018Y0142E	018Y0342E	018Y0144E	017G0648E	017G0050E		012AX970E	015M2971E	012A1975E	018L0032E



## PAPER



	PerfectFinish Photo Paper			Premium Photo Paper				Photo Paper	
	0019Y0190	0019Y0200	0019Y0205	0021G0710	0021G0711	0080D1707	0021G0709	0080D1706	0021G0708
Format	10x15 cm	10x15 cm	A4	10x15 cm	10x15 cm	A4	A4	A4	A4
Number of Pages	50	100	50	20	60	15	50	20	50
Weight	255 g	255 g	255 g	240 g	240 g	240 g	240 g	190 g	190 g

## LEXMARK PAPERS & TRANSPARENCIES

Part Number	Papers & transparencies						
	Laser Banner Paper (21 x 91.4 cm) Box of 50	Laser Banner Paper (29.7 x 91.4 cm) Box of 50	Glossy Paper A4 Box of 200	Outdoor Media A4 Box of 100	Transparencies A4 Box of 50	Transparencies A4 Box of 50	Transparencies A4 Box of 50
	0012A8940	0012A7940	0012A5951	0012A8601	0012A8241	001053741	0012A5010
Lexmark E250, E352, E450							•
Lexmark C522, C524, C530, C532, C534			•		•		
Lexmark C500, C510, C522, C524, C530, C532, C534, X500, X502, X560	NEW		•		•		
Lexmark C720, X720			•		•		
Lexmark C750, C752L, C760, X750, X752			•		•		
Lexmark C752			•	•	•		
Lexmark C762, X762	•		•	•	•		
Lexmark C770, C772, X772	•		•	•	•		
Lexmark C780, C782	NEW		•	•	•		
Lexmark C910			•		•		
Lexmark C912, X912		•	•		•		
Lexmark C920, C935, X940, X945	NEW		•		•		
Lexmark E120							•
Lexmark E210, E320, E322, E321, E323, E340, E342							•
Lexmark E232, E330, E332							•
Lexmark E240							•
Lexmark T420, T430, T630, X630, T632, X632, T634							•
Lexmark T520, X520, T522, X522, T620, T622						•	
Lexmark T640, T642, T644							•
Lexmark W812							•
Lexmark W820, X820, X830, X832							•
Lexmark W840							•
Lexmark X215, X422							•
Lexmark X340							•
Lexmark X642, X644, X646							•
Lexmark X850, X852, X854							•
Optra C710			•		•		
Optra Color 1200			•		•		
Optra E310/ E312/ E312L							•
Optra E							•
Optra K 1220							•
Optra M410/ M412							•
Optra N						•	
Optra S						•	
Optra Se 3455						•	
Optra SC 1275			•			•	
Optra T/ T610/ T612/ T614/ T616						•	
Optra W810							•
4019, 4028, 4029, 4027-4W, 4037-5E, 4039/ 4039+, 4047-5E/ 4047-5W						•	•
ValueWriter 300/ 600							•
WinWriter 200/ 400/ 600							•
4039 10+, 4049, Optra L/ R Series						•	•

## LEXMARK MATRIX SUPPLIES

Part Number	Ribbons			
	General Purpose Ribbon 001040864	General Purpose Ribbon 0013L0034	23XX/ 24XX Black Re-inking Ribbon 0011A3540	24XX High Yield Black Re-inking Ribbon 0011A3550
4226	•			
4227/ 4227 Plus		•		
2480/ 81, 2490/ 91, 2380/ 81, 2390/ 91 & 2380+			•	
2480/ 81, 2490/ 91				•
2500 Series	NEW		•	•

# LEXMARK LINEA™ PRINT CARTRIDGES FOR HP AND CANON PRINTERS

Part Number Printer Engine	00140100A	00140109A	00140127X/A	00140191A	00140195A	00140196A	00140198X/A
	BX	WX	52X	NX	SX	EP-32	EX
<b>Model</b>							
<b>Apple</b>							
LaserWriter II F/ II G/ IINT/ IISC					•		
LaserWriter I NTX/ II NTX/ IISX					•		
LaserWriter Pro 600/ 630							•
LaserWriter 16/ 600 PS							•
<b>Brother</b>							
HL 8/ 8E/ 8J/ 8II/ 8D/ 8PS					•		
HL 8J/ 8PSAP/ 8V					•		
HL10/ 10DV/ 10PS/ 10V/ 10H					•		
HL 8PSJ	•						
HL1260/ 1660/ DX/ E/ NE/ NTR/ PS							•
<b>Calcomp</b>							
CCL1200 ES/ 600 - ES - XF	•						
<b>Canon</b>							
LBP 2460		•					
LBP B 406G	•						
LBP 200V/ 8 II/ 8 II F/ 8 II R					•		
LBP 8 II SX/ 8 II T/ 8 III/ 8IIIR					•		
LBP 8 III Plus/ 8 III T/ RX/ SX/ TX					•		
LBP 8 IV/ 8 Mark IV/ EX/ P270							•
LBP 860/ 1260							•
LBP NX/ NX600				•			
LBP BXII	•						
LBP 1000/ EP-32						•	
LBP 1760/ 1760E/ 1760NE/ 1760TNE/ 52X			•				
<b>DEC</b>							
Printserver 17/ 600				•			
DECLaser 2100/ 2150					•		
DECLaser 2200/ 2250					•		
LN 05/ LN 06					•		
DECLaser 5100							•
<b>GENICOM</b>							
6100 Series/ 6145					•		
9170				•			
9080	•						
<b>Hewlett-Packard</b>							
LaserJet Series II/ IID/ III/ IIID					•		
LaserJet 4/ 4M/ 4+/ 4M+							•
LaserJet 5/ 5M/ 5N							•
LaserJet 4V/ 4MV	•						
LaserJet III Si/ 4Si/ 4Si MX				•			
LaserJet 2100/ 2100SE/ 2100XI/ 2100M/ 2100TN						•	
LaserJet 2200/ 2200D/ 2200DT/ 2200DN/ 2200DTN						•	
LaserJet 4000/ 4000N/ 4000T/ 4000TN			•				
LaserJet 4050/ 4050N/ 4050T/ 4050TN			•				
LaserJet 5Si/ 5Si MX/ 5Si NX/ 5Si Mopier		•					
LaserJet 8000/ 8000N/ 8000DN		•					
<b>Lexmark</b>							
Optra N						•	
<b>OCE</b>							
6450/ 6451	•						
<b>Olivetti</b>							
PG 108					•		
<b>QMS</b>							
1725/ SLS/ E Print Systems				•			
2308 S/ 3308S/ Kiss Plus					•		
Lasergraphix 810/ 820					•		
PS 810/ 810II/ 810 Turbo					•		
PS 815/ 820/ 820 Turbo/ 825					•		
Turbo Imageserver XP					•		
860 Plus/ 1660 Plus	•						
2425		•					